

## MANUAL DEREGISTRATION CODE

CONNECTING			Deregistration Process:
SL80108	TL90078	CL80109	*331734#(MENU/SELECT)
SL81108	TL91178	CL81109	
SL81208	TL91278	CL81209	
SL82218	TL91378	CL81309	
SL82318	TL92178	CL82109	
SL82418	TL92278	CL82209	
SL82458	TL92328	CL82309	
SL82518	TL92378	CL82359	
SL82558	TL92478	CL82409	
	TL90078	CL82509	
	TL91178	CL82609	
	TL91278	CL82659	
		CL82859	

## MANUAL DEREGISTRATION CODE

OOR or No pwr at base			Deregistration Process:
CL80100	CL8XXX5	TL90070	<p>*331734#(MENU/SELECT)  <b>NOTE: * Models TL86109/TL86009, TL88102/TL88002,                      TL96XX7, CLP99XX7</b>                      Press *331734# + left softkey</p>
CL81200	CL841X2	TL91270	
CL82100	CRL32XX2	TL91370	
CL82200	CRL8XXX2	TL92220	
CL82250	CLP99XX3	TL92270	
CL82300	CLP99XX6	TL92320	
CL82350	CLP99XX7	TL92370	
CL82400		TL92420	
CL82450		TL92470	
CL82500		TL86009*	
CL82550		TL86109*	
CL82600		TL88102*	
CL84100		TL88002*	
CL84200		TL9XXX1	
CL8XXX1		TL9XX73	
CL824X3		TL86103*	
CL8XXX3		TL86003*	
CL8XXX4		TL96XX6	
CL8XXX7		TL96XX7	

## MANUAL DEREGISTRATION CODE

NO LINK TO THE BASE	Deregistration Process:
Syn-J Deskset(SB67148) & Cordless Handset(SB67108)	<p>1. Press MENU/ENTER on handset, (MENU on deskset).</p> <p>2. PRESS *883247# on handset/deskset, arrow up once, press MENU on the handset (SELECT on the deskset.)</p> <p>3. <b>Handset</b> - Disconnect the battery. Wait 10 seconds, and then reconnect battery. The handset will display the registration instructions.</p> <p><b>Deskset</b> – Disconnect the ac power. Wait 10 seconds and then reconnect the ac power. The deskset will display the registration instructions.</p> <p><b>NOTE: The Main Base can remain powered for this procedure.</b></p>
NO DISPLAY	Deregistration Process:
TL7600	Remove the headset from its base and press the key sequence: VOL+, MUTE, VOL-, and MUTE. VOL+, VOL-, MUTE. The headset LED will flash blue and orange indicating it is not registered.
TL7800	Remove the headset from its base and press the key sequence: VOL+, ON/OFF, VOL-and ON/OFF. VOL+, VOL-, ON/OFF. The headset LED will flash blue and orange indicating it is not registered.
CONNECTING	Deregistration Process:
TL7601	Press *331734#SEL

## MANUAL DEREGISTRATION CODE

OOR or No pwr at base	Deregistration Process:
TL32XX0	<ol style="list-style-type: none"> <li>1. Press Menu/Select. Display reads: Play messages if it has a TAS or Directory if not.</li> <li>2. Enter *7890#. Display reads: &gt;Test Base Test Handset</li> <li>3. Scroll to &gt;Test Handset; press Menu/Select. Display reads: &gt;SW Version.</li> <li>4. Scroll to &gt;Register Clear; press Menu/Select.</li> <li>5. Display reads: Reg Clear ?AR on top line. Press Menu/Select.</li> <li>6. Display reads: OKClear ?AR on top line. Press and hold OFF until Out of range OR No pwr at base is displayed.</li> <li>7. Unplug battery/s; wait a few seconds, then reconnect.</li> <li>8. The registration instructions will appear on the display. Register the handset as you normally would.</li> </ol>
EL5XXX3, AWX2XXX4	<ol style="list-style-type: none"> <li>1. Press Menu/Select. Display reads: Play messages if it has a TAS or Directory if not.</li> <li>2. Enter *7890#. Display reads: &gt;Test Base Test Handset</li> <li>3. Scroll to &gt;Test Handset; press Menu/Select. Display reads: &gt;SW Version.</li> <li>4. Scroll to &gt;Next Page...; press Menu/Select.</li> <li>5. Display reads: LCD TEST on top line. Scroll to &gt;Register Clear, Press Menu/Select.</li> <li>6. Display reads: Reg Clear? Press Menu/Select. Press and hold OFF until Out of range OR No pwr at base is displayed.</li> <li>7. Unplug battery/s; wait a few seconds, then reconnect.</li> <li>8. The registration instructions will appear on the display. Register the handset as you normally would.</li> </ol>

OOR or No pwr at base	Deregistration Process:
EL5XXX5	<ol style="list-style-type: none"><li>1. Press Menu/Select.</li><li>2. Enter *7890#.</li><li>3. Scroll to &gt;Test Handset; press Menu/Select. Display reads: &gt;SW Version.</li><li>4. Scroll to &gt;Register Clear, Press Menu/Select.</li><li>5. Display reads: Reg Clear? Press Menu/Select. Press and hold OFF until Out of range OR No pwr at base is displayed.</li><li>6. Unplug battery/s; wait a few seconds, then reconnect.</li><li>7. The registration instructions will appear on the display. Register the handset as you normally would.</li></ol>